

Hemp can be mixed with NHL 2, to create an insulating plaster. There are 40L of NHL 2 per bag. We recommend mixing a bag of NHL 2 with 40L of Hemp, while adding approx 20L of water. Ideally you mix the lime and water first and create a slurry then adding the Hemp. This can be thrown on the wall or applied with a hawk and trowel. Can also be applied using your hands.

## Mixing of hemp plaster:

Step 1 : Water into the mixer (20L)

Step 2: NHL 2 (25kg)

Step 3: Mix lime and water thoroughly

Step 4: Hemp (40L)

Step 6: Test on wall

Step 7: Add more water if necessary

For a finish on the hemp plaster you could use Monolys/Lime Putty/ NHL/H-1 Binder. Always do a mock-up! Try not to make the mix too wet!

For Hempcrete, Mix NHL 5 and hemp. Shutter the wall for Hempcrete. Always do a mock-up!

## Mixing of Hempcrete:

Step 1: Add 10L of water (10L)

Step 2: NHL 5 (25kg)(30L)

Step 3: Hemp (60/65L)

Step 4: Add another 10L of water.